# LINOVISION

Outdoor PoE Switch

POE–Switch1108GP

User Manual

Updated on October 12, 2022

Package Contents

Outdoor PoE Switch

|	
1 AC Power Cord	**2** Metal Straps
1 Screws	**2** Hanging Installation Kit
1 Passive 24V PoE Converter	**1** LINOVISION Special Cable
1 Manager Board	**1** User Manual

Product Overview


Front Panel

Back Panel

- Wall-Mount Hole
- Heat Sink
- Cable Hole

Top Panel

- Hanging Mount Hole

Inside

- SFP Slot
- LED Indicators
- RJ-45 Ports
- LED Indicators
- Passive 24V POE Converter

1

| Light	Instruction	Status	Status Description
LAN Green Light	Signal Indicator	Green Light Blinked	If the green light does not flicker , please check whether the external network equipment is normal
PoE 1-8 Red Light	PoE Power Supply	Red Light ON	If the red light goes out , please check PD
PoE 1-8 Green Light	Power Network State	Green Light Blinked	If the green light does not flicker , please check whether the external network equipment is normal
PWR	Power Indicator	Blink Red	The device power on is normal

Passive 24V POE Output

LINOVISION Special Cable ┄┄┄┄┄

Passive 24V POE Output

Wireless Bridge

Hardware Installation

Pole-mount

1

2

Wall-mount

1

2

4 x Screw with long size

3

Hanging Mount

1

2 x Screw with medium size

2

3

2 x Screw with long size

4

# Network cable installation

Open the box

Push down and open to the right

Connect Cable

Connect Power

Close the box

1 x Screw with small size

Specification

1 x 1000Mbps SFP Slot

2 x 1000Mbps PoE Ports 802.3bt 60W PoE

AC 110-240V

6 x 100Mbps 802.3af/at PoE Ports

2 x 1000Mbps Ethernet Ports

Product	POE-Switch1108GP
Hardware	V2
Ports	6 x 100Mbps PoE Ports 2 x 1000Mbps PoE Ports 2 x 1000Mbps Ethernet Ports 1 x 1000Mbps SFP Slot
PoE Output Port	6x802.3af/at PoE+2x802.3bt 60W PoE
Power In	AC 110-240V
PoE Watchdog	Yes
PoE Budget	120W
Application Environment	-30℃ ~ 70℃

CE FC RoHS