Hi-PoE Midspan User's Manual

V1.0.5

Important Safeguards and Warnings

Please read the following safeguards and warnings carefully before using the product in order to avoid damages and losses.

Note

- Do not expose the device to lampblack, steam or dust. Otherwise it may cause fire or electric shock.
- Do not install the device at position exposed to sunlight or in high temperature. Temperature rise in device may cause fire.
- Do not expose the device to humid environment. Otherwise it may cause fire.
- The device must be installed on solid and flat surface in order to guarantee safety under load and earthquake. Otherwise, it may cause device to fall off or turnover.
- Do not place the device on carpet or quilt.
- Do not block air vent of the device or ventilation around the device. Otherwise, temperature in device will rise and may cause fire.
- Do not place any object on the device.
- Do not disassemble the device without professional instruction.

Warning:

- Please use battery properly to avoid fire, explosion and other dangers.
- Please replace used battery with battery of the same type.
- Do not use power line other than the one specified. Please use it properly. Otherwise, it may cause fire or electric shock.

Special Announcement

- This manual is for reference only.
- All the designs and software here are subject to change without prior written notice.
- All trademarks and registered trademarks are the properties of their respective owners.
- If there is any uncertainty or controversy, please refer to the final explanation of us.
- Please visit our website for more information.

Table of Contents

1	Pro	oduct Overview	
1	.1	Features	1 -
1	.2	Typical Application	1 -
2	De	vice Structure	2 -
2		Appearance Port	
		nt panel	
	Rea	ar panel	2 -
3	Ins	stallation Guide	3 -

1 Product Overview

Hi-PoE Midspan is mainly used to provide PoE transmission for IPC. Meanwhile, it is equipped with PoE extender with multilevel cascade, providing long-distance PoE transmission for IP Camera.

1.1 Features

- Support Hi-PoE 60W PTZ camera PoE transmission.
- Port: 1*RJ45 10/100/1000M non-PoE port, 1*RJ45 10/100/1000M PoE port.
- Indicator status: power (normal power on), PoE (Ethernet power supply).
- Operating temperature: -30°C~65°C.
- Installation mode: wall mount.

1.2 Typical Application

See Figure 1-1 for mode details about typical networking scene.




Figure 1-1

2 Device Structure

2.1 Appearance Port

Front panel

The front panel is shown in Figure 2-1.




Figure 2-1

Refer to Table 2-1 and Table 2-2 for more details.

Indicator	Note	Color	Device Status						
PWR	Power status indicator	Green	Normal power connection						
PoE	PoE power output indicator	Green	Normal power supply transmission						
Table 2-1									

Port Name	Note				
DATA	1*10/100/1000M RJ45 port, used to connect to uplink device, it only				
	transmits Ethernet data for non-PoE port.				
PoE	1*10/100/1000M RJ45 port, used to connect to IP Camera or PoE				
	extender, PoE power supply.				
Table 2-2					

Rear panel

The rear panel is shown in Figure 2-2.





Figure 2-2

Refer to Table 2-3 for more details.


Port Name	Note	
Power Port	Three-core power cable port, support AC 100~240 V,	50/60HZ input

3 Installation Guide

Hi-PoE Midspan supports wall mount. Please refer to Figure 3-1 for more details.



Please refer to Figure 3-2 for the device dimension.





Note

- This user's manual is for reference only.
- Slight difference may be found in user interface.
- All the designs and software here are subject to change without prior written notice.
- All trademarks and registered trademarks are the properties of their respective owners.
- If there is any uncertainty or controversy, please refer to the final explanation of us.
- Please visit our website for more information.